

"Grip for Bead Lifting Tools" – Installation Instructions

Items Needed

- Grip for Bead Lifting Tools
- Quick Dry Rubber Cement
- Tire Bead Lifting Tool
- Nitrile Gloves + Eye Protection

Safety Notes

- **DO NOT** use a knife to remove old tape or grips from the tool
- **ALWAYS** wear nitrile gloves when performing this procedure, as excess rubber cement may leak out during installation.
- **ALWAYS** wear safety glasses.

Installation Instructions

1. Remove any existing tape or grips from tool and clean thoroughly.
2. Apply quick dry rubber cement thoroughly to the inside of the rubber grip, as far in as you can go.
3. Apply quick dry rubber cement to the end of the tool. Cover the end of the tool as far as the grip will go (~7").
4. Slide the grip over the end of the tire bar and remove any excess cement with a rag or cloth. Allow it to dry overnight. The fit is designed to be tight to allow the grip and tool to securely bond together.

